

Tel: 1.877/.546.1148 - Fax: (949) 7/16.6129 - Sales@Fastener-Express.com

See Charts below to locate correct hex key for socket and torx screws

Shop Hex Keys now Click Below! www.fastenerexpress.com/index.asp?PageAction=VIEWCATS&Category=217

Torque and Screw Interchangeability

Hex Size		e Capac			Screw Interchangeability						
TICA SIZE	Bondhus®		Bondhus®			T	1		7		
Inch	Straight Hex		Ball End Tip								
0.50	in-lb	Nm	in-lb	Nm		-	(3)	100	8		
.050	7.9	0.892	3	0.339	0	1, 2	1, 2	3, 4			
1/16	15.9	1.796	7	0.0791	1	3, 4	3, 4	5, 6			
5/64	34	3.842	13	1.469	2, 3	5, 6	5, 6	8			
3/32	51	5.763	24	2.712	4, 5	8	8	10			
7/64	84	9.492	39	4.407	6	10					
1/8	129	14.57	57	6.441			10	1/4	1/4		
9/64	185	20.90	86	9.718	8	1/4			Ī		
5/32	265	29.94	127	14.35	10	5/16	1/4	5/16	5/16		
3/16	431	48.7	189	21.35	1/4	3/8	5/16	3/8	3/8		
7/32	673	76.04	318	35.93		7/16	3/8	7/16	ļ		
1/4	950	107.3	482	54.44	5/16	1/2		1/2	1/2		
5/16	2022	228.4	888	100.3	3/8	5/8	1/2	5/8	5/8		
3/8	3005	339.5	1488	168.1	7/16, 1/2		5/8	3/4	3/4		
7/16					9/16	3/4					
1/2					5/8			7/8	1		
9/16		Ī						1, 1-1/8			
5/8					3/4			1-1/4, 1-3/8	1-1/4		
3/4					7/8, 1			1-1/2			
7/8					1, 1 1/4						
1					1 3/8, 1 1/2						
1 1/4					1 3/4	Ī	Ī				
1 1/2					2						
1 3/4					2 1/4						
2 1/4					3						
Hex Size	Torque Capacity**				Screw Interchangeability						

www.fastener-express.com

taylenet-exbress.com

Tel: 1.877/.546.1148 - Fax: (949) 716.6129 - Sales@Fastener-Express.com

Metric	Bondhus® Straight Hex		Bondhus® Ball End Tip		7	Ĩ			1
	in-lb	Nm	in-lb	Nm				-	
1.27			3	3.39	1.4			2.5	
1.5	13.1	1.480	5	.565	1.6, 2			3	
2	33	3.729	13	1.469	2.5	3	3	4	
2.5	63	7.119	33	3.729	13	1.469	2.5	5	
3	106	11.97	52	5.876	4	5	5	6	5
3.5			70	7.910					
4	264	29.83	131	14.8	5	6	6	8	6
4.5									
5	483	54.57	247	27.91	6	8	8	10	8
5.5									
6	855	96.61	396	44.74	8	10	10	12	10
7									
8	1861	210.2	989	111.7	10	12	12	14, 16	12
9									
10	3563	402.6	1591	179.7	12	14,16	14, 16	18, 20	16
12					14	18,20	18,20	22,, 24	20
14					16, 18	22, 24	22,24	Ī	
17					20, 22			Ī	
19					24, 27			Ī	
22					30	ļ		ļ	
27					36				

^{**}Minimum torque capacities Bondhus® tools generate without breakage. Other manufacturer's tools may break with considerably less torque.

Torx® Screw Interchangeability



Tel: 1.877/.546.1148 - Fax: (949) 716.6129 - Sales@Fastener-Express.com

(Bondhus® BallStar™ keys fit all of the following screw types)											
Size					h r					€	
	Pan Head		Flat Head		Socket Head		Socket Button		Truss Head		Fillster Head
	Inch	Metric	Inch	Metric	Inch	Metric	Inch	Metric	Inch	Metric	Inch
1		M0.9		M0.9 & M1		M0.9					
2		M1		M1.2		M1					
3		M1.2	#0								
5	#0	M1.4 & M1.6	#1	M1.6 & M1.8		M1.4 & M1.6					
6	#1	M1.8 & M2	#2	M2	#0	M1.8 & M2	#2		#2		#1
7	#2				#1		#3		#3		#2
8	#3	M2.5	#3 & #4	M2.5	#3 & #4	M2.5	#4	M3	#4		#3
10	#4 & #5	M3	#5 & #6	M3	#4 & #5	M3	#5 & #6	M3.5	#5 & #6	M3.5	#4 & #5
15	6	M3.5	#8	M3.5	#6	M3.5	#8	M4	#8	M4	#6
20	#8	M4	#10	M4					#10	M5	#8
25	#10	M5	#12	M5	#8	M4	#10	M5	#12		#10
27	#12		1/4		#10	M4.5 & M5	1/4	M6	1/4		#12
30	1/4	M6		M6	1/4	M6			5/16	M6	1/4
40	5/16	M8	5/16	M8		M7	5/16	M8	3/8	M8	5/16
45	3/8		3/8		5/16	M8	3/8	M10	7/16		3/8
50	7/16	M10	7/16 & 1/2	M10	3/8	M10			1/2	M10	7/16
55	1/2	M12	9/16 & 5/8	M12	7/16 & 1/2	M12	1/2	M12 & M14	9/16 & 5/8	M12	1/2 & 9/16
60	Ì		3/4		9/16	M14	5/8	M16	3/4		5/8
70					5/8	M16					3/4
80					3/4	M18					
90						M20		ļ			
100					7/8 & 1	M22 & M24					

www.fastener-express.com